
## Installation Instructions

- 1 -

Universal 2U Rack Mount for 4P Dual-Head

## **PARTS:**

- 1 HMT14239 x 2 Mounting Bracket for 4P DH units Black
- (2) HFT14889 x 4 Screw M2 5x7mm Phillips / Pan Head / Steel
- ③ HFT16316 x 4 Screw M5x16mm Pan Head Phillips Steel DIN7985A
- (4) **HFT16317 x 6** Screw 12x3/4" Deep Thread Wood, Philips, PH
- (5) HMT16312 x 2 2U Under the table bracket for 8P DH




©2021 All rights reserved. HSL logo and product names are trademarks or service trademarks of HighSecLabs Ltd (HSL). All other marks are the property of their respective owners. Images for demonstration purposes only.

## Installation Instructions

Universal 2U Under the Table Rack Mount for 4P Dual-Head

- 2 -



©2021 All rights reserved. HSL logo and product names are trademarks or service trademarks of HighSecLabs Ltd (HSL). All other marks are the property of their respective owners. Images for demonstration purposes only.